
FIG. 1 CABANE GUSSET INST. 6 IN. LEFT.
FIG. 2 LONGERON END DETAIL 6 IN. LEFT.
FIG. 3 LONGERON END DETAIL 6 IN. LEFT.
FIG. 4 LONGERON DETAIL 6 IN. LEFT.
FIG. 5 LONGERON DETAIL 6 IN.
FIG. 6 TUBE & FITTING INST. 6 IN. LEFT.
FIG. 7 STAB. ADJ. FITTING'S INST. 6 IN. LEFT.
FIG. 8 FITTINGS ASSY. 6 IN. LEFT.
FIG. 9 LANDING GEAR TRUSS INST. 6 IN. LEFT.
FIG. 10 SIDE FRAMES INST. 6 IN. LEFT. (ON 1040 ONLY)
FIG. 15 PULLEY BUSHING INST. 6 IN. LEFT.
FIG. 16 PULLEY BUSHING INST. 6 IN. LEFT.
SECTION A-A
SECTION B-B
SECTION C-C 3 IN. LEFT.
SECTION D-D 6 IN. LEFT.
SECTION E-E 6 IN. LEFT.
SECTION F-F 6 IN. LEFT.
SECTION G-G 3 UNIT.
SECTION H-H 6 IN. LEFT.
SECTION J-J FULL SIZE
SECTION K-K FULL SIZE
SECTION M-M FULL SIZE
SECTION T-T
SECTION V-V
SECTION Z-Z (ON 1040 ONLY) FULL SIZE
SECTION Z-X FULL SIZE
SECTION U-T-K FULL SIZE
SECTION V-V FULL SIZE
SECTION U-U FULL SIZE
SECTION R-R FULL SIZE
SECTION Q-Q FULL SIZE
SECTION P-P FULL SIZE
VIEW L-L 3 IN. LEFT.
BOTTOM BAY DIAGONAL TUBE
SIDE FRAME ASSY.
FLOOR FITTINGS INST. 11142
LANDING GEAR STRUT FITTINGS INST. 11145
SEAT FITTINGS INST. (1338 IN 1040 ONLY) (10470 IN 1040S ONLY)
ELEVATOR PULLEY BRACKET INST. 11098
ELEVATOR STOPS & STABILIZER SUPPORT INST. 11164
STAB. LEAD SCREW UPPER BEARING INST. 20491
FUSELAGE SIDE MEMBER
FUSELAGE TAIL FITTINGS INST. 20492
FITTING HANDLE INST. 20692
HORIZ. REF. LINE
TALK WELD
DRILL #31
NOSE ELEVATOR 27° UP. 18° DOWN
STAB 1° 15' UP 5° 30' DOWN
NOTES:
1. PARTS MARKED (L) USED ON LEFT SIDE OF FUSELAGE ONLY.
2. PARTS MARKED (R) USED ON RIGHT SIDE OF FUSELAGE ONLY.
3. DOTTED LINES IN TOP VIEW INDICATE TRANSVERSE MEMBERS.
4. STABILIZER TRAVEL MEASURED RELATIVE TO THE HORIZ. REF. LINE SHOULD BE 11° 30' UP AND 5° 30' DOWN.
ASSY NO. - REMARKS
11040 - SHOWN & NOTED
11040-S - SHOWN & NOTED
FRAME ASSY. - FUSELAGE
PIPER AIRCRAFT CORP.
LOCK HAVEN, PENNA.
11040